KEP EvalBench

The KEP EvalBench is used to test the KEP. It can download listing files to the KEP, sned and receive signals and execute single ticks.

Installation

The KEP Eval Bench is only running under Windows. It is located in the repository in: Verifier/development/KepEvalBench. Some necessary libraries are located in the libs subdirectory.

The computer on which the KEP Eval Bench runs must be connected to the KEP via COM1.